














LINEA TV






Що знадобиться для збирання.


A1  x16	A2  x16	B1  x27
C1  x8	D1  x14	E1  x4
E2  x4	F1  	F2  x8
G1  4x16 x32	H1  3.5x30 x3	I1  x17
J1  		
L1  x4		
M1  x1		







Елементи меблів.






49	80	x	318	1
50	1802	x	412	1
51	1768	x	383	1
52	862	x	358	1
53	435	x	410	1
54	435	x	410	1
55	358	x	358	1
56	358	x	358	1
57	155	x	804	1
58	155	x	804	1
59	1768	x	60	2
60	862	x	120	1
61	156	x	351	1
62	156	x	351	1
66	1780	x	370	1
67	817	x	330	1
63	254	x	856	1
64	371	x	450	1
65	371	x	450	1





1




2




3










4







5




X2







14




15




16









17




18







19




20




21




23




24



25





26




27


28




29



30



31



32

