















# ERGOSENS LUX






# Что понадобится для сборки.

<b>A1</b> 	<b>A2</b> 	<b>B1</b> 
<b>C1</b>  15mm	<b>D1</b> 	<b>E1</b> 
<b>E2</b> 	<b>F1</b> 	<b>G1</b> 
<b>H1</b> 	<b>I1</b> 	<b>J1</b> 
<b>K1</b>  30mm	<b>L1</b>  25mm	



KONSTAN  
МЕБЛЕВА ФАБРИКА




# Элементы мебели.




1	2400	616	1
2	2400	580	1
3	2227	580	1
4	1768	580	1
5	1768	580	1
6	1184	559	2
7	568	559	4
8	384	559	1
9	384	559	1
10	80	1768	1
11	80	1768	1
12	199	561	2
13	61	1768	1
14	Ящик		2
15	Дверь передняя		1
16	Дверь задняя		1

1A	2237	569	1
2A	2237	1194	1


1




2




3










7




8



5





6













7



8



9



10

