















ERGOSENS LUX






Что понадобится для сборки.

A1 	A2 	B1 
C1  15mm	D1 	E1 
E2 	F1 	G1 
H1 	I1 	J1 
K1  30mm	L1  25mm	



KONSTAN
МЕБЛЕВА ФАБРИКА





Элементы мебели.




1	2468	600	1
2	2468	600	1
3	2400	600	1
4	2400	600	1
5	2227	600	1
6	2227	600	1
7	1100	579	1
8	1100	579	1
10	668	579	5
11	668	579	5
12	384	579	1
13	2468	80	1
14	2468	80	1
15	307	579	1
16	2468	61	1
17	Ящик		4
18	199	661	2

1A	2236	1108	1
2A	2236	676	2


1




2





3




4




5




6





7



8





9




10





11









15

